




*Fig. 1*




*Fig. 2*




*Fig. 3*




*Fig. 4*




*Fig. 5*



*Fig. 6*



*Fig. 7*



*Fig. 8*

Figure 9 is a dialog box 810 asking 'HAVE YOU LOADED HP MEDIA?'. It has a 'YES' button and a 'NO' button.

*Fig. 9*

Figure 10 is a dialog box 810 asking 'WHICH HP MEDIA ARE YOU LOADING?'. It has a list of media types: HP COATED MEDIA, HP HEAVY COATED MEDIA, HP UV VINYL MEDIA, HP PHOTO GLOSS MEDIA, HP SEMI-GLOSS PHOTO MEDIA, HP BOND MEDIA, and HP BACKLIT MEDIA.

*Fig. 10*




Fig. 11